



EVOKE SQUARE TRIMLESS PLASTER FRAME INSTALLATION

689-0186

1. CUT OUT DIMENSION FOR APERTURE
IS $4\frac{1}{16}$ " (SEE FIG. 1).

2. INSTALL PLASTER FRAME OVER
HOUSING APERTURE. SECURE PLASTER
FRAME WITH THE (4) 6-32 SCREW
SUPPLIED (DO NOT SUBSTITUTE
HARDWARE FOR THIS STEP)

WARNING: SUBSTITUTION OF
HARDWARE MAY RESULT IN INJURY.
USE FACTORY SUPPLIED HARDWARE

3. INSTALL CARDBOARD PLUG PRIOR
TO THE APPLICATION OF JOINT
COMPOUND OR PLASTER.
NOTE: IF CARDBOARD PLUG IS NOT
SUPPLIED, MAKE SURE THAT THE
INSIDE OF APERTURE IS CLEANED.

4. APPLY JOINT COMPOUND UP TO LIP
EDGE OF PLASTER FRAME. SAND AND
FINISH PER STANDARD PRACTICES.

5. SEAL AND PAINT

6. REMOVE CARDBOARD PLUG AND
CLEAN INSIDE SURFACE AS NEEDED.

7. INSTALL TRIM

