



# EVOKE ROUND TRIMLESS PLASTER FRAME INSTALLATION

- CUT OUT DIMENSION FOR:**
  - E2.9 IS 4  $\frac{1}{16}$ " DIA. (SEE FIG. 1).
  - E4.75 IS 5  $\frac{7}{8}$ " DIA.

- INSTALL PLASTER FRAME OVER HOUSING APERTURE AND REST ALIGNMENT MARKER WITHIN THE NOTCH OF THE APERTURE AS SHOWN (SEE FIG. 2). THEN SECURE PLASTER FRAME WITH THE (4) 6-32 SCREW SUPPLIED (**DO NOT SUBSTITUTE HARDWARE FOR THIS STEP**)

**WARNING: SUBSTITUTION OF HARDWARE MAY RESULT IN INJURY. USE FACTORY SUPPLIED HARDWARE**

- INSTALL CARDBOARD PLUG PRIOR TO THE APPLICATION OF JOINT COMPOUND OR PLASTER. **NOTE: IF CARDBOARD PLUG IS NOT SUPPLIED, MAKE SURE THAT THE INSIDE OF APERTURE IS CLEANED.**

- APPLY JOINT COMPOUND UP TO LIP EDGE OF PLASTER FRAME. SAND AND FINISH PER STANDARD PRACTICES.

- SEAL AND PAINT

- REMOVE CARDBOARD PLUG AND CLEAN INSIDE SURFACE AS NEEDED.

- INSTALL TRIM

