INSTRUCTION SHEET



ROOK WALL INDIRECT "FLIP KIT"

689-0842

PAGE 1 OF 1

WARNING - RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY. FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL SPECIFICATIONS. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING.


RETAIN THESE INSTRUCTIONS FOR MAINTENANCE REFERENCE.

1 FLIP ARM BRACKET*

A LOOSEN AND REMOVE (2X) SCREWS

B ROTATE ARM BRACKET 180°


C ATTACH ARM BRACKET WITH (2X) SCREWS



*THIS STEP IS OPTIONAL. ITS INTENT IS TO HIDE THE ARM BRACKET END PLATE SCREWS.

2 ATTACH DUST COVER

- A LOCATE MIDDLE CLIP AWAY FROM WALL
- B PUSH DUST COVER CLIPS INTO GAP BETWEEN TRIM AND HOUSING



Amerlux, 178 Bauer Drive, Oakland, N.J. 07436, T: 973-882-5010, F: 973-882-2604 www.amerlux.com