INSTRUCTION SHEET



689-0556

## AMERLUX REMOTE MOUNTED CURRENT LIMITING **DEVICE WITH RIGID STEM SUSPENSION**

PAGE 1 OF 1

WARNING - RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY. FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL SPECIFICATIONS. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING. **RETAIN THESE INSTRUCTIONS FOR MAINTENANCE REFERENCE. CONCRETE / HARD LID CEILING JUNCTION BOX MOUNTING** CEILING SURFACE  $\bigcirc$ ( )J-BOX (BY OTHERS) SUSPENSION CURRENT LIMITING DEVICE CANOPY / STEM TO BE ORDERED SEPARATELY FIELD CUTTABLE STEM NON-LIVE END TRACK MOUNT -TRACK LIVE END TRACK MOUNT **GRID / DROP CEILING JUNCTION BOX MOUNTING** CEILING SURFACE CURRENT LIMITING DEVICE / CANOPY TO SIT EVEN WITH CEILING SURFACE NON-LIVE END TRACK MOUNT LIVE END TRACK MOUNT NOTE: GES TRACK SHOWN. SUSPENSION HARDWARE WILL VARY FOR OTHER TRACK TYPES Amerlux, 178 Bauer Drive, Oakland, N.J. 07436, T: 973-882-5010, F: 973-882-2604 www.amerlux.com

amerlux INSTRUCTION 689-0516 SHEET ACLREM REMOTE MOUNTED CURRENT LIMITING DEVICE PAGE 1 OF 1 WARNING - RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY. FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL SPECIFICATIONS. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING. **RETAIN THESE INSTRUCTIONS FOR MAINTENANCE REFERENCE. 1. ATTACH ACLREM BASE PLATE** 2. WIRE BREAKER(S) **TO JUNCION BOX** (HARDWARE SUPPLIED BY OTHERS) **4" OCTAGONAL JUNCTION BOX -**Б **SUPPLIED BY OTHERS** 618-0395 (12AWG 9" BLACK WIRE) IN FROM LINE **E** ē 618-0396 (12AWG 9" RED WIRE) 0 0 NICE N OUT TO LOAD HARDWARE SUPPLIED BY OTHERS NOTE: LOAD AND LINE TERMINAL MARKINGS ON BREAKERS **3. INSTALL COVER** USE SUPPLIED T10 DRIVER BIT TO TIGHTEN SUPPLED M4 TAMPER RESISTANT SCREWS Amerlux, 178 Bauer Drive, Oakland, N.J. 07436, T: 973-882-5010, F: 973-882-2604 www.amerlux.com

DATE